



COLLAGEN FILM BECKDORIN

TECHNOLOGICAL RECOMMENDATIONS:

The film is completely ready for use. It does not need to be pre-prepared before use. It should not be soaked in water or other solutions, and dried. It is important not to allow moisture to get on the film or its roll. The surfaces of the applicator that the film comes into contact with during the filling process, must be dry. The film and its roll can only be taken with dry hands. If the manufacturing process is interrupted for more than 30 minutes, the roll of the collagen film should be removed from the applicator, and placed in a plastic bag, to avoid moisture on its surface.

The collagen film is a delicate material, so when using it on the applicator, careful handling is recommended.

The collagen film can be used for smoking at temperatures up to 76°C. The heat treatment time is the standard time required for manufacturing smoked products.

Heat treatment:

Stage 1: drying at temperature of 60°C for 20-40 minutes.

Purpose: during the drying process, the film is permanently sintered with the surface of the meat product.

Stage 2: smoking with dry smoke at temperature of 65-68°C for 15-30 minutes.

Purpose: to give the product an even color.

Stage 3: cooking at temperature of 70°C for 15-20 minutes, then post-cooking or smoking with steam at temperature not exceeding 76°C.

Storage

The film should be stored in packs in a covered, dry, clean warehouse, protected from sunlight, at temperature of 10-20°C, and relative humidity of 50-70%, at a distance of at least 1 m from heating devices, water and sewer pipes.

The shelf life is: 12 months in the sealed package, 14 days in the opened package.